

Macros


for



cncCUT



BLECHCENTER Plus




ncCAD32

Overview




IBE Software GmbH; Friedrich-Paffrath-Straße 41; 26389 Wilhelmshaven


Fon: 04421-994357; Fax: 04421-994371; www.ibe-software.de; Info@ibe-software.de




M_051




M_052




M_053



M_054




M_055




M_056


<p style="text-align: center;">M_057</p>	<p style="text-align: center;">M_058</p>
<p style="text-align: center;">M_059</p>	<p style="text-align: center;">M_060</p>
<p style="text-align: center;">M_061</p>	<p style="text-align: center;">M_062</p>




M_063




M_064



M_065















M_066










M_067


<p style="text-align: center;">M_076</p>	<p style="text-align: center;">M_077</p>
<p style="text-align: center;">M_078</p>	<p style="text-align: center;">M_079</p>
<p style="text-align: center;">M_080</p>	<p style="text-align: center;">M_081</p>









 <p>A diagram of a triangle with a vertical dashed line from the top vertex to the base. Dimension lines with arrows indicate: 'H' for the height, 'B' for the distance from the left base corner to the dashed line, and 'A' for the total base length.</p>	
<p>M_100</p>	

